

T1000 Release Settings

W. Wafler/D. Billet

13-Sept-2012

Software Configuration

GUI Version: t1000_2.0.1.56_2.0.1.51.msi

Procedure

1. Before installing version 2.0.1.56, the PC must have been updated to at least 3492 and all the changes that go along with that release.
2. Install new software, t1000_2.0.1.56_2.0.1.51.msi, located in PC Software\ T1000 Control Program. **Note:** during the installation, when the installer pops up the “Copy Configuration” window, it often appears behind the main install window. Make sure it is brought to the foreground and select the previous version so the printer specific config files get copied to the new version.
3. Navigate to c:\Program Files\T1000\2.0.1.56(2.0.1.51)\diagnostics prints and unzip alignment prints to the diagnostics prints folder.
4. Start the GUI.
5. Run Profile Gantry from the Service Tab. Once the gantry profiling is complete, quit the GUI and restart. This must be done for the new gantry profile to take effect.
6. After the gantry is profiled, the gantry orthogonality value needs to be re-adjusted. Print Orthogonality.ism in the diagnostics folder and re-adjust the value in Setup->Options as necessary.